

# UFO-2050

## Main Control Unit



- Four (4) links in rear panel for daisy connection
- Supports up to **10** chairman units & **999** delegate units (with extension power supply)
- **4x20** digit LCD for showing and setting conference configuration
- **Multiple Conference Modes:**
  - **NORMAL/OVERRIDE/CHAIRMAN**
  - **FIFO:** 1. Delegates can turn on/off mics freely. 2. When maximum open mic qty is reached, the next microphone will go into request-to-speak status.
  - **OPEN-MIC:** Numbers of microphone that can be turned on meanwhile (**1-30**)
  - **VOICE (MIC Auto-Off):** Microphone automatically turn off in **10-99** seconds when not in use
- **System Auto-Test** starts when turn on; Microphone light ring flashes when connecting error
- Delegate microphone can be turned off by pressing chairman control button (beep when activated)
- **RS-232** interface integrates with BXB graphical control software
- Built-in video auto-track interface
  - Two (**2**) auto-tracking mode:
    - BUTTON/VOICE**
- LED volume indicator
- Built-in sound-emission circuit to prevent echo and noise
- **Digital Volume Adjustment**

### TECHNICAL SPECIFICATIONS

Frequency response	100HZ~16KHZ
LINE IN :	-4dB~+6dB $\geq$ 10K $\Omega$ ( Balanced )
LINE OUT :	-4dB~+12dB $\geq$ 200 $\Omega$ ( Balanced )
Sensitivity :	-60dB
T.H.D. :	$\leq$ 0.5%
S/N Ratio :	$\geq$ 90dB
Conference microphone connection :	RJ45 express port x 4 sets
Volume Indicators	5 LEDs
Power	DC 18V/6A
DC Power Supply Fuse	DC 250V/8A
Height x Width x Depth	100 x 430 x 230 (mm)
Weight	8 (kg)

\*Appearances and specifications of all items may subject to change without pre-notice.