

KRAMER



Installation Instructions

MODEL:

C-A35M/IRRN

3.5mm to IR Receiver Cable



P/N: 2900-300583



Rev: 1



SAFETY WARNING

Disconnect the unit from the power supply before opening and servicing

For the latest information on our products and a list of Kramer distributors, visit our Web site where updates to this user manual may be found.

We welcome your questions, comments, and feedback.

www.kramerAV.com

info@kramerel.com

The C-A35M/IRRN 3.5mm to IR Receiver Cable

Congratulations on purchasing your Kramer **C-A35M/IRRN** 3.5mm to IR Receiver Cable.

The **C-A35M/IRRN** is used to remotely control the machine.

The **C-A35M/IRRN** is available in two lengths:

- The **C-A35M/IRRN-3**, 3' (0.90m) long (Kramer P/N: 95-0104003)
- The **C-A35M/IRRN-50**, 50' (15.20m) long (Kramer P/N: 95-0104050)



IMPORTANT: Before using this kit, check that your machine has a REMOTE IR 3.5mm mini jack installed on its rear panel.

The distance between the remote controller and the machine can be extended to up to 60 meters using the optional Kramer Stereo cables, 15 meters each (**Kramer P/N 95-0103050**).



3.5mm Mini Jack

IR Receiver

The External Remote IR Receiver connects to the 3.5mm mini jack on the rear panel of the machine. Once connected, the Kramer machine can be controlled from a distance.

Installing the C-A35M/IRRN

1. Turn the machine off.
2. Connect the 3.5mm mini jack of the External Remote IR Receiver cable to the 3.5mm jack on the rear panel.
3. Turn the machine on.



Note that once the **C-A35M/IRRN** is connected, the built-in front panel IR receiver is disabled.

Electrical Check

To make sure that the cable is properly connected, point the remote control transmitter at the external IR Receiver and press a few buttons to make sure that it works properly.

Every time you press the remote control buttons, the LED in the remote IR receiver and the LED in the built-in IR receiver blink.