

KRAMER



USER MANUAL

MODEL:

VIA Campus

Collaboration Device for Education
and Training Environments
(For Firmware Version 1.9)

Contents

1	Introduction	1
2	Getting Started	2
2.1	Achieving the Best Performance	2
2.2	Safety Instructions DC	2
2.3	Recycling Kramer Products	3
3	Overview	4
3.1	Applications & Features	5
3.2	Defining the VIA Campus Collaboration Device	6
4	Setting Up VIA Campus	7
4.1	Connecting VIA Campus to a Display	8
4.2	Downloading and Running VIA Campus Software	9
4.3	Using an .msi File	11
4.4	Logging-In to VIA Campus	11
4.5	Logging-In to VIA Campus by QR Code Scanning	12
4.6	Logging-in to VIA Campus Using a VIA Pad	13
4.7	Logging-in to VIA Campus Using a VIA NFC Tag for Android	14
4.8	Using iOS /Android Mirroring to Share your Screen	14
5	Defining VIA Campus Functions	19
6	Using VIA Campus	23
6.1	VIA Campus User's Main Menu	23
6.2	Enabling Control	25
6.3	Chatting with Participants	26
6.4	File Transfer	27
6.5	Multimedia	29
6.6	View Main Display	35
6.7	Start Collaboration	36
6.8	VIA Cloud	38
6.9	Whiteboard Collaboration	39
6.10	Whiteboard Functions	40
6.11	Calling with Skype	43
6.12	Using GoToMeeting	43
6.13	Using WebEx	43
6.14	Using Microsoft Lync	44
6.15	Accessing a Web Page	44
6.16	Using the Settings Menu	45
6.17	Managing Settings from the VIA Web Management Interface	63
6.18	User Experience	81
7	Technical Specifications	85
8	VIA Campus Upgrade Procedure	86
8.1	Downloading the Upgrade File	86
8.2	Upgrading your VIA Campus	86
8.3	Verifying a Correct Installation	86
8.4	Updating your Computer Client Applications (Windows and MAC)	87
8.5	Updating the Mobile Applications	87

Figures

Figure 1: VIA Campus Collaboration Device	6
Figure 2: Connecting the VIA Campus Collaboration Device	8
Figure 3: VIA Campus Admin Features	19
Figure 4: VIA Campus Main User Screen	21
Figure 5: The Participant List	24
Figure 6: Enable Control	26
Figure 7: Chat Window	27
Figure 8: Admin File Sharing	28
Figure 9: User File Sharing	28
Figure 10: Shared Files on the Cloud	38
Figure 11: Whiteboard Toolbar	40
Figure 12: Wide Desktop	41
Figure 13: Multiple Screen	41
Figure 14: Settings Screen	46
Figure 15: LAN Settings Screen	47
Figure 16: Room/Name Code Screen	48
Figure 17: Configurations Screen	49
Figure 18: System Control Screen	51
Figure 19: Wallpaper Screen	52
Figure 20: Third Party Apps Screen	53
Figure 21: Setting Application Name	54
Figure 22: Authentication Screen	56
Figure 23: Moderator Mode	58
Figure 24: Login Screen When Moderator Mode is Active	59
Figure 25: VIA Management - Network Settings	65
Figure 26: VIA Site Management	69
Figure 27: VIA Management – Authentication	76
Figure 28: VIA Management – Gateway Features	77
Figure 29: VIA Management – Client Features (MAC/Windows)	78
Figure 30: VIA Management – Client Features (Mobile)	78
Figure 31: Samsung Galaxy	83
Figure 32: iPhone/iPad	83
Figure 33: PC	84

1 Introduction

Welcome to Kramer Electronics! Since 1981, Kramer Electronics has been providing a world of unique, creative, and affordable solutions to the vast range of problems that confront video, audio, presentation, and broadcasting professionals on a daily basis. In recent years, we have redesigned and upgraded most of our line, making the best even better!

Our 1,000-plus different models now appear in 14 groups that are clearly defined by function: GROUP 1: Distribution Amplifiers; GROUP 2: Switchers and Routers; GROUP 3: Control Systems; GROUP 4: Format/Standards Converters; GROUP 5: Range Extenders and Repeaters; GROUP 6: Specialty AV Products; GROUP 7: Scan Converters and Scalers; GROUP 8: Cables and Connectors; GROUP 9: Room Connectivity; GROUP 10: Accessories and Rack Adapters; GROUP 11: Sierra Video Products; GROUP 12: Digital Signage; GROUP 13: Audio; and GROUP 14: Collaboration.

Congratulations on purchasing your Kramer **VIA Campus Collaboration Device**. This product, that incorporates HDMI™ technology, is ideal for:

- Projection systems in conference rooms, classrooms, training rooms, boardrooms, auditoriums and hotels
- Creating a collaborative environment in the previous venues

2 Getting Started

We recommend that you:

- Unpack the equipment carefully and save the original box and packaging materials for possible future shipment
- Review the contents of this user manual



Go to www.kramerav.com/downloads/VIA_Campus to check for up-to-date user manuals, application programs, and to check if firmware upgrades are available (where appropriate).

2.1 Achieving the Best Performance

To achieve the best performance:

- Use only good quality connection cables (we recommend Kramer high-performance, high-resolution cables) to avoid interference, deterioration in signal quality due to poor matching, and elevated noise levels (often associated with low quality cables)
- Do not secure the cables in tight bundles or roll the slack into tight coils
- Avoid interference from neighbouring electrical appliances that may adversely influence signal quality
- Position your **VIA Campus** away from moisture, excessive sunlight and dust



This equipment is to be used only inside a building. It may only be connected to other equipment that is installed inside a building.

2.2 Safety Instructions DC



Caution: There are no operator serviceable parts inside the unit

Warning: Use only the Kramer Electronics power supply that is provided with the unit

Warning: Disconnect the power and unplug the unit from the wall before installing

2.3 Recycling Kramer Products

The Waste Electrical and Electronic Equipment (WEEE) Directive 2002/96/EC aims to reduce the amount of WEEE sent for disposal to landfill or incineration by requiring it to be collected and recycled. To comply with the WEEE Directive, Kramer Electronics has made arrangements with the European Advanced Recycling Network (EARN) and covers any costs of treatment, recycling and recovery of waste Kramer Electronics branded equipment on arrival at the EARN facility. For details of Kramer's recycling arrangements in your particular country go to our recycling pages at <http://www.kramerelectronics.com/support/recycling/>.

3 Overview

Welcome to **VIA Campus**!

Student engagement is critical to successful learning. With advanced collaboration and engagement tools, **VIA Campus** maximizes the learning experience by making Education and Corporate Training environments more interactive.

With any laptop or mobile device, students and teachers can view the main display, edit documents together in real time, turn the main display into a digital whiteboard, share any size file, and more. **VIA Campus** also lets teachers use e-polling and e-exams to easily and instantly measure how much students are actually learning.

VIA Campus converts any display at any location into an interactive meeting point, and it works with a wide range of presentation devices from desktop and notebook computers to tablets and smartphones.

Each participant in a **VIA Campus** session can quickly view, edit, annotate, comment and share content with other participants. Participants can share their ideas through the primary screen, or break off with others into smaller groups during a meeting.

VIA Campus integrates seamlessly with any organization's current IT infrastructure, converting any projector or screen into a networked device that users can share and view on their current devices. Every local connection to **VIA Campus** is wireless, free of dongles, cables, and other compatibility peripherals.

Key features of **VIA Campus**:

- Login using conventional Wi-Fi or LAN connections, no dongle needed.
- Provides true HD 1080p/60 video streaming.
- Supports Windows laptops and MAC®, as well as iOS, Android mobile operating systems and Windows phone.
- MSI compatible with all common Web browsers.
- Up to 255 users can be logged in simultaneously.

- Up to 12 participant screens can be displayed simultaneously on dual screens (six on each screen).
- Supports popular third-party conferencing programs.
- e-Polling and e-Exam (in Beta version only).
- Touchscreen compatible with whiteboard and full annotation controls.

3.1 Applications & Features

Present, share, chat, send and receive files, hold sidebar conversations, annotate, edit, and save copies of all your work, just as you would with a whiteboard or flip chart – all from your notebook computer, tablet, and smartphone.

VIA Campus provides the following:

- **Multiviewing:** Up to six different participant screens can be shown at the same time. **VIA Campus** automatically sizes each screen to the maximum available resolution, displaying tiles for two or more screens. Finished sharing? Tap Step-out to disconnect.
- **Chat and share a file:** Need to ask a meeting participant a question? Click on their screen name and send them a text message with complete privacy. Windows and Mac PC users can also share files between themselves or the main presenter, all at the click of a mouse.
- **Control a participant's computer:** Need to access files or play back a presentation from a participant's PC? Simply click Enable Control on the PC, and its cursor can be controlled remotely to launch programs and play media.
- **Multimedia:** Sometimes it's just easier to explain your ideas with a video. Simply click the Multimedia tab on your device's screen and you can load and display JPEG images (all operating systems) and play MP4 videos from any platform. You can also display and share PDFs from any logged-in device. **VIA Campus** features a 10Mbps maximum video bitrate for 30fps or 60fps videos and handles video files of up to 8GB.
- **Device mirroring:** Are you using an iOS device with no VIA application? Just mirror your device's screen to the main display by activating the Airplay service of your device. Are you an Android user? Use the VIA App to start mirroring your device and its content!

3.2 Defining the VIA Campus Collaboration Device

This section defines **VIA Campus**.



Figure 1: VIA Campus Collaboration Device

#	Feature	Function
1	Power Button	For turning the machine on and off
2	USB 2.0 Connector	For upgrading firmware or connecting a USB device
3	DC IN 19V Connector	Connects to the 19V DC power supply
4	USB 3.0 connectors	Connect to up to 2 USB devices
5	DISPLAY OUT DVI-I Connector	Connects to a DVI display
6	eSATA Connector	Connect an eSATA drive to expand your storage
7	DISPLAY OUT HDMI Connector	Connects to an HDMI display
8	LAN RJ-45 Connector	Connects to a wireless router or to a LAN
9	USB 2.0 Connectors	Connect to up to 2 USB devices
10	AUDIO LINE OUT 3.5mm Mini Jack	Connects to an unbalanced stereo audio acceptor
11	MIC IN 3.5mm Mini Jack	Connects to a microphone

4 Setting Up VIA Campus



Always switch off the power to each device before connecting it to your **VIA Campus**. After connecting **VIA Campus**, connect its power and then switch on the power to each device.

To connect the **VIA Campus** as illustrated in the example in [Figure 2](#) you need:

- A **VIA Campus** Wireless Collaboration Hub.
- A display (projector, monitor, or screen).
- **NOTE:** A touchscreen display is best for annotation.
- A Local Area Network (LAN) cable for connection to your network. For wireless network connectivity, use a commercial wireless router.

The following client devices can be used with Kramer's **VIA** collaboration hub:

- A Windows 7/8/10® (32-bit/64-bit) computer.
- A Macintosh® computer, using OSX 10.7.x or newer.
- An iPad/iPhone® tablet/smartphone with the **VIA** app installed (iPad 2 or later, iOS 7.0 or later).
NOTE: When using the Airplay service, no application is needed (refer to iOS mirroring section)
- An Android® OS 4.x tablet/smartphone with the **VIA** app installed.
- A Windows® phone with the **VIA** app installed.

These optional add-ons can enhance your **VIA Campus** system:

- A USB camera for distant participants connecting through Lync®, Skype®, GoToMeeting®, or WebEx®.
- A conferencing speakerphone for remote communication as well as audio playback of content being shared on the display.




Figure 2: Connecting the VIA Campus Collaboration Device

4.1 Connecting VIA Campus to a Display

VIA Campus is equipped with dual display output connections.

- The HDMI connection is used with any compatible projection or direct-view display, such as an LCD monitor. This connection carries embedded audio, that routes and switches like any other HDMI connection
- The DVI-I connection is used with compatible projection or direct-view displays. Unlike the HDMI port, the DVI-I jack does not carry embedded audio and requires a separate audio connection

The **VIA Campus** internal video card reads the Extended Display Identification Data (EDID) for any connected display and sets the optimum display resolution and image refresh rate automatically through the HDMI connector.

For full functionality, **VIA Campus** must be connected to a local area network (LAN). You may assign a fix IP address to the **VIA Campus**. However, your **VIA Campus** is set on DHCP mode by default.

NOTE: To allow participation in a collaborative session (send and receive content), connect the **VIA Campus** hub and all participant devices (PCs/ MACs/ smartphones/tablets) to the same network (LAN - wired/wireless).

VIA Campus hub receives user's display/screen information and multimedia files from their device (laptop/tablet/smartphone) and sends them to the collaboration display (the display connected directly to **VIA Campus** hub unit).

4.2 Downloading and Running VIA Campus Software

All participants in a meeting must download and run either the Kramer **VIA** executable file (PC, Mac) or the appropriate Android/iOS app.

To access the PC and Mac executable files:

- Open your Web browser and enter the IP address for your VIA Campus unit
- Your Web browser recognizes your OS (MAC/Windows) and directs you to the correct client software
- Choose from the following two options:



- To run the VIA app virtually (without installing on your computer), select "Click to **Run** VIA". Once downloaded, locate the file on your computer (under "Downloads") and click to launch it. The **VIA Campus** login screen appears
- To permanently install the VIA app, select "Click to **Install** VIA". It downloads an .exe file to your computer and asks if you want to run this file. Click **Yes** and follow the Setup instructions. The VIA app is saved to the KRAMER folder on your C: drive. It creates a shortcut on the desktop for easy access.

VIA
KRAMER

Room Name

Nick Name

Code

Login

For tablets and smartphones, find the Kramer **VIA** app in the App Store (iOS) and Google Play (Android).

Alternatively, open your Web browser on your mobile device and enter the IP address for your **VIA Campus** unit.

- Choose from the following two options:



- Download the app to your tablet/phone and install. When the app is run, the following screen appears:

VIA
KRAMER

Room Name

Nick Name

Code

Login

V-1.9.0316.316
Powered By WOW Vision
Your Will Connection Name: Hadasa's_Network

4.3 Using an .msi File

IT managers can use the VIA .msi file for easy deployment and installation of the VIA application on the user's clients.

To find the .msi file:

1. Browse your unit for (make sure you are on the same network):
http://<ip of box>/files/VIAApp.msi.
2. Replace "<ip of box>" by the valid Room Name.
3. Save the file on your PC.

4.4 Logging-In to VIA Campus

Windows and Mac OS

1. Choose a username (nickname) for your device (any mix of letters and numbers) then enter it on the login screen.
2. Next, enter the room code (if enabled), seen on the lower right part of the screen. This accesses **VIA Campus**.

iOS, Android & Windows Phone

1. First, enter the IP address for **VIA Campus** (found on the main display screen in the lower left).
2. Next, choose a username (nickname) for your device (it can be any mix of letters and numbers) then enter it on the login screen of your device.
3. Finally, enter the room code (if enabled) as seen on the lower right part of the screen. This accesses **VIA Campus**.


4.5 Logging-In to VIA Campus by QR Code Scanning

iOS, Android & Windows Phone

1. Launch the application on your mobile device and click the QR code icon (on the lower right corner).



2. Put your mobile device in front of the VIA main display QR code (found on the VIA main display screen in the lower right corner).



3. You are automatically logged in to **VIA Campus**.

4.6 Logging-in to VIA Campus Using a VIA Pad

Windows and Mac OS

- Pressing once: Steps you in (When you start, the LED banner on the device is blue. After stepping in, it changes to green).



- Pressing twice: Freezes your screen (the banner on the device changes from green to flashing green). To unfreeze and resume, press twice again.
- Pressing once again: Steps you out.
- Long press to display on the full screen when you are not the only one who is already stepped in.

4.7 Logging-in to VIA Campus Using a VIA NFC Tag for Android

To write an NFC tag:

- Install the VIA NFC Writer on an Android device.
- Open VIA NFC Writer.
A page similar to a VIA page opens
- Enter the room name and click **Write tag**.
- When prompted, touch the Android device on the writable tag.
Another prompt confirms that the tag has been successfully written.

To use the NFC tag:


- Enable the NFC feature on an Android device.
- Touch the Android device on the tag:
 - IF VIA is installed – The VIA application launches and automatically logs into VIA Campus. The room code is bypassed.
 - IF VIA is in the background – Same as above.
 - IF VIA is not installed – The Google play store page is launched with a VIA application download option. Install the VIA Android application.
 - If VIA installed and connected – A prompt asks the user to logout before touching the tag with an Android device.

4.8 Using iOS /Android Mirroring to Share your Screen


All participants in a meeting using an Apple device can mirror their screen by using the Airplay service. No application is required to activate this mode. However, **VIA Campus** unit must run firmware version 1.8 or later and iOS mirroring feature must be enabled (see the “settings” section for more details).

4.8.1 Mirroring From your iOS Device (iPhone or iPad/Mini iPad)

1. Connect your Apple device to the network where **VIA Campus** resides.
2. Swipe up from the bottom of the iPad or iPhone to reveal the Control Center.




3. Click AirPlay and choose the **VIA Campus**'s AirPlay device name. By default the VIA's AirPlay device is named VIA_AirMirror_XXXX, where XXXX is a random combination of letters and numbers.
4. To stop mirroring, disconnect the device properly by as follows:
Swipe up from the bottom and swipe the toggle button to disconnect mirroring then tap to select "iPhone/iPad" accordingly.
Note: If the room code is enabled on **VIA Campus**, you are prompted to enter the same 4-digit security code when attempting to mirror you iOS device. This code appears on the main screen of **VIA Campus**.



4.8.2 Mirroring MacBooks and Apple Computers

1. Connect your Apple device to the network where **VIA Campus** resides.
2. Click the AirPlay menu on the Apple Menu Bar, located in the top-right corner of the screen near the clock.




3. Choose the AirPlay device name of **VIA Campus**.

By default, the VIA's AirPlay device is named VIA_AirMirror_XXXX, where XXXX is a random combination of letters and numbers.

Note: If the Room Code is enabled on **VIA Campus**, you are prompted to enter the same 4-digit security code when attempting to mirror your iOS device. This code appears on the main screen of **VIA Campus**.

4.8.3 Mirroring Android Devices

1. Your device must support Android 5.0 version as a minimum.
2. Make sure the VIA application is installed on your device. See [Section 4.2](#) for details.
3. Connect your Android device to the network where **VIA Campus** resides.
4. Log in to the application by entering the Room Name and Nickname fields and room code if enabled.



5. Click on Step-In. The device shows this message: "VIA will start capturing everything that's displayed on your screen." Please accept by clicking on "START NOW".
6. You can now minimize the VIA app by clicking on the "Home" button of your device. Your screen is mirrored on the main display.
7. To stop sharing your screen, re-open the VIA application and click on Step-out.

Note: Android mirroring does not support audio. Audio is heard from your device and not from the output of the VIA device.

5 Defining VIA Campus Functions

VIA Campus presents two types of screens depending upon whether it is being used by the Admin or by a User. The following screen shots illustrate both types.

The illustration below shows the **VIA Campus** main Admin screen and its functions:



Figure 3: VIA Campus Admin Features

Item	Icon	Action
1	Features	Allows the user to see and access all available features of VIA Campus
2	Whiteboard	Opens a canvas to annotate, draw, and update document collaboratively over a live stream
3	Participants	Provides a list of all participants in the session
4	Cloud	Open the Cloud and all the files that are saved or shared between participants
5	Skype	Starts the Skype video conferencing tool
6	Go to Meeting	Starts a GoToMeeting session
7	WebEx	Starts a WebEx session
8	Microsoft Lync	Opens Lync client for audio and video conferencing
9	Web Browser	Opens the browser at the VIA Campus gateway to present any content directly from the Web site
10	Screen Share	Pushes a mirror of the VIA Campus collaboration display on the user's devices (laptop, iPad, MacBook, Android tablet). The user can see all the activities of the VIA Campus collaboration display on his system (this feature is called "View Main Display" in the Client menu)
11	Third Party Apps	Shows third-party applications installed and integrated with VIA Campus
12	File Transfer	Shares files between the available participants during the session
13	Chat	Allows the sending of chat messages among available participants during that session
14	Shut Down	Shuts down the VIA Campus system
15	Reboot	Reboots the VIA Campus System
16	Settings	Performs settings on the LAN, configurations related to room code, room name third-party apps, system controls, wallpaper streaming configuration and activation center
17	Display Layout	Allows selecting the layout when several participants are stepped-in (thumbnail view or dynamic view)

The illustration below shows the **VIA Campus** main User screen and its functions:




Figure 4: VIA Campus Main User Screen

Item	Icon	Action
1	Features	Allows user to see and access all available features of VIA Campus
2	Step-In/ Step-Out	Allows the user to show his device's screen on the main display, or to step out
3	Participants	Provides a list of all participants in the session
4	Multimedia	Supports video formats: avi, vob, mp4, mov, mpx (ex. mpg). Shares smooth full-motion video (up to 1080p/60) and photos
5	Cloud	Drag and drop files to the cloud to share instantly with everyone in the session
6	Microsoft Lync	Opens Lync client for audio and video conferencing
7	Whiteboard	Opens a canvas to annotate, draw, and update document collaboratively over a live stream
8	Start Collaboration	Click to collaborate through a common display using your own device. Multiple users can interact and control the main display at the same time
9	View Main Display	Shows a mirror of the VIA Campus collaboration display on the user's devices (laptop, iPad, MacBook, Android tablet). The user can see all the activities of the VIA Campus collaboration display on his system (this feature is called "Screen Share" in the Admin menu)

Item	Icon	Action
10	Chat	Allows sending chat messages among available participants during that session
11	Enable Control	Gives participants control over the presenters Mac or PC laptop
12	File Transfer	Shares files between the available participants during the session
13	3 rd Party Apps	Open the third-party applications installed and integrated with VIA Campus

6 Using VIA Campus

VIA Campus is a powerful and versatile collaboration hub that gives participants a wide selection of presentation tools. This section describes each of the tools and how they work.

6.1 VIA Campus User's Main Menu

This section refers to the user's experience. Once you have logged in to VIA, the Parent Dashboard displays on your home-screen. This Parent Dashboard provides basic navigation through VIA. The Parent Dashboard displays your main navigation icons, "Features," "Step-In" and "Participants." Each one of these three icons represents the core functionality of VIA. The section below identifies and defines each icon.

- Clicking the Features tab on the main menu allows the user to see and access all available functions of **VIA Campus**.
- Clicking the Step-In tab on the main menu displays your PC/device screen on the main screen. After selecting the icon, the "Step-In" button will automatically change its displayed name to "Step-Out." Once you have finished sharing/displaying your content, you select "Step-Out" to remove your desired content from the display.
- Clicking the Participant List tab reveals a list of all participants in the session. It also opens the capability for "Chat" and "File-Sharing" functionality with the other participants.




Figure 5: The Participant List

Under Participants, the following icons are used:

Item	Icon	Meaning
Display Status		Start a presentation at a display
		The user is currently presenting
Chat Status		Start a chat session with any available participants
		The participant is currently chatting with you. Click to open the chat session

Item	Icon	Meaning
File Transfer		Start a file transfer with another participant
		File transfer is already active with that participant
Enable Control		Take control of any user while the user is displaying
		Admin has the control of that user

6.2 Enabling Control

This function allows the admin to take control of a participant's PC (Windows or Mac OS). (In our example, [Figure 6](#), user *Jim* has stepped in and the Admin has taken control of *Jim*):

The admin can work on Jim's system as he has taken control. (Admin can play media or work on a document or presentation file collaboratively with *Jim*).

Any other participant who wants to take control or collaborate with *Jim's* system can click on the Start Collaboration icon and drag his laptop mouse to the top and off their local screen. That cursor now moves to **VIA Campus** and appears on the main display of *Jim*. Buttons are shown in the picture below:




Figure 6: Enable Control

6.3 Chatting with Participants

The admin or user can start a chat session to exchange text messages between users.

To initiate a chat session:

- Go to the participant list and click the chat icon  for the desired participant. The chat window opens and you can chat with selected participant:




Figure 7: Chat Window

In the chat window, the participant's name is at the left side of the window and your chat messages are on the right side.

The user can check for active chat sessions by going to *Features > Chat*.



6.4 File Transfer

VIA Campus can transfer files between PC/Mac/Mobile Devices logged in users.

To share a file:

- Go to the participant list and click on the file share icon  for the desired participant with whom you wish to share a file.
- In the cloud directory, select the desired file on your device. Then, click Share. 




Figure 8: Admin File Sharing

- The target participant needs to select a location to save the file and start the file transfer process. Once completed, the file is saved on that participant's system.




Figure 9: User File Sharing

- When completed, the file is saved at receiver's system. You can check or cancel currently sharing file from *Features > File Transfer*.



File Transfer

6.5 Multimedia

This section explains the various forms of handling multimedia.

6.5.1 Video Player

VIA offers users the ability to play video at a full HD 1080p/60fps rate. Full 1080p/60fps video is obtained by streaming the video from the VIA Client application to the VIA Gateway. The video file never leaves the user's client device and is not transferred to VIA.

Below are the two ways you can play video from VIA:

- File Searching Media Files
 - Select "Multimedia" from your features menu on the parent dashboard.
 - Click Add Media in the lower left corner.
 - Select a video you would like to add and click "Open".
 - The file is then displayed within the "My Media" section.
 - Double-click the media file and the video begins playing.
- Drag/Drop Media directly to VIA
 - On the left-hand side of the VIA parent dashboard you see a small VIA logo.
 - Select the file you want to play from any folder on your device.
 - Drag the file to the logo only. The video does not play if you try to drag the file to the left, right, below or above the logo.
 - Once released, the video automatically starts playing.

Note: When showing videos through VIA, the video is not being transferred from your device to the VIA unit. All videos are being encoded directly on your BYOD device through the VIA software and then streamed from your device to the VIA unit. The VIA unit then decodes the streamed file for playback.

Note: Without using the VIA software, media files can be played from your device using native media players you have installed such as QuickTime and/or Windows Media Player. However, if you choose this method and do not use VIA for video playback, your video will be only mirrored to the display. Using this method, you may experience lower frame rates, inconsistent playback and increased latency.


6.5.2 RTSP Streaming Through VLC


The Real Time Streaming Protocol (RTSP) is a network control protocol designed for use in entertainment and communications systems to control streaming media servers. The protocol establishes and controls media sessions between end points. Clients of media servers issue commands like play and pause, to facilitate real-time control of playback of media files from the server.

VIA Campus supports RTSP. A media being played locally on a computer can be streamed on a **VIA Campus** unit, provided the computer and **VIA Campus** are on connected networks.


For RTSP Streaming using VLC:

1. Open VLC.
2. Click **Media > Stream**.
3. Click **Add** and select a file to stream and click **Stream**.







4. Click **Next** on the next screen.



5. Choose RTSP from the **New Destination** drop down and click **Add**.
6. Enter a short name to be used as **Path**, uncheck **Activate Transcoding** and click **Next**.



7. Check **Stream all elementary streams** and click **Stream**.




8. Open **VIA Campus** client and click **Features > Multimedia > Streaming Player**.

9. Type a name as the URL name.

10. The URL takes the path from:

`rtsp://<local computer IP address>:8554/<name mentioned in step 6>`



11. Click **Add Media**.
12. Select RTSP stream and click the play button to stream this media on **VIA Campus**.

6.5.3 RTP Streaming Through VLC

The Real-time Transport Protocol (RTP) is a network protocol for delivering audio and video over IP networks. RTP is used extensively in communication and entertainment systems that involve streaming media, such as telephony, video teleconference applications, television services and Web-based push-to-talk features.

VIA Campus supports RTP. A media can stream on a **VIA Campus** unit, provided the computer and VIA Campus are on connected networks.

To stream RTP using VLC:

1. Open VLC.
2. Click **Media > Stream**.
3. Click **Add** and select a file to stream and click **Stream**.
4. Click **Next** on the next screen.
5. Choose **RTP/MPEG Transport Stream** from the **New Destination** drop down and click **Add**.
6. Enter **VIA Campus** unit's IP address and click **Stream**.
7. Open **VIA Campus** client and click **Features > Multimedia > Streaming Player**.
8. Type a name as the URL name.
9. The URL path takes the form:
Rtp://<VIA Campus IP address>:5004
10. Click **Add Media**.
11. Select the RTSP stream and click the play button to stream this media on **VIA Campus**.
Note: if a URL is already present in the streaming list above, VIA client generates a warning for both modes – RTP and RTSP.

6.6 View Main Display

By selecting View Main Display, a live view of the main screen is displayed on the user's device to allow a closer look at the presentation.

Note: View Main Display is designed for visual reinforcement and is shown at a reduced frame rate in an effort to reduce bandwidth usage. It is not intended for watching full motion video, as the playback on the client device appears choppy.

To use View Main Display:

1. Select the View Main Display icon from the Features menu on the Parent Dashboard.

The screen automatically shows a live representation of the main display.

2. Zoom in/out of the captured image.
 - Pinch to zoom in on tablets and smartphones.
 - +/- Percentage zooming on PCs & Macs.
3. Use basic whiteboarding functionality on the bottom (mobiles) or the left (laptops) of the screen to:
 - Draw, erase, add notes and save the file.
 - Choose various color options.
 - Create annotations that allow the user to take notes locally on their device without affecting the presentation.

4. To exit View Main Display, select the Features icon from the Parent Dashboard.

Note: Saved image captures are available under the Multimedia section of the Parent Dashboard under "Documents."

6.7 Start Collaboration

VIA Campus offers state-of-the-art collaboration functionality. VIA allows up to 255 meeting participants to collaborate. The Start Collaboration function allows a user to use their mouse and keyboard on VIA gateway.


Note: In the description below, we describe a scenario with only two users for simplicity.

User #1 is showing content from their device

User #2 is collaborating with User #1's content


- Collaboration begins when User #1 Steps-In and begins displaying content.
- With content being shown, User #1 then selects Enable Control from the dashboard. At this point, all connected users have full control of User #1's computer.

“Enable Control” is the function that can be electively enabled to allow other users to share control of their computer
- Once “Enable Control” is selected, a red check mark appears on the upper-right of the icon.



Note: To disable this functionality once the collaborative session has ended, select the same Enable Control icon and the red button disappears. Once deselected, no other participants have access to that computer.

- User #2, who can now see User #1's content, selects the Start Collaboration button.



- User #2 can bring their mouse onto the main display by moving their mouse to the top of their local screen (as if VIA's main display was an extended desktop).
- Once User #2 has scrolled up, an additional cursor with User #2's name on it appears on the screen.
- Each participant nickname is displayed with a custom colored cursor.
- At this point, User #2 can access and make changes to the displayed content.
 - Note:** User #2 has complete access to User #1's computer, beyond the file/content being displayed.
- Once the collaborative session has ended, the content can be saved to the hard drive of User #1's computer. If desired, User #1 could use the "File Sharing" capabilities of VIA to share the edited document with all participants.
- The person who is sharing their content now clicks the same Disable Control icon, disabling the ability for any other participant to control/modify their content.

6.8 VIA Cloud

The VIA “Cloud,” or VIA hard drive, is *internal* memory storage only. Selecting Cloud launches a standard file management system, enabling you to select files to be stored directly on the VIA unit. **VIA Campus** has 60 Gb of internal memory.

The Cloud on the client user interface is the feature used to send a file from your computer to all participants. A copy of all shared files is also stored on the VIA Cloud.

On **VIA Campus**, the user is given two options when they select a file to share:

- Share the file just to VIA – to open it locally on **VIA Campus** to view and edit (for example - share an Excel spreadsheet to the Campus to open and edit as a group).
- Share the selected file with all connected participants.
Note: You can map your Cloud to any external memory storage or network drive through the "Settings" feature of your VIA.

The Cloud directory looks like this on your VIA device:




Figure 10: Shared Files on the Cloud

- To delete a single file from the cloud directory, click on the Trash icon . A warning note appears that this is a permanent deletion.
- To delete all files from the cloud directory, click on Clean Directory. A warning note appears that this is a permanent deletion.

6.9 Whiteboard Collaboration

The whiteboard function creates a canvas on the **VIA Campus** hub. With the whiteboard, you can:

- Access a wide range of drawing and annotating tools
- Comment on any content shown on screen
- Insert any kind of images
- Annotate on an extended desktop

To open the Whiteboard:

- Go to the main menu and click on the Whiteboard icon
This starts a whiteboard session on **VIA Campus**.

6.10 Whiteboard Functions




Figure 11: Whiteboard Toolbar

Item	Icon	Action
1	Pen	Enables drawing on the whiteboard
2	Color	Changes the color of the line with various available colors
3	Size	Chooses the line thickness
4	Eraser	Erases your annotations
5	Erase All	Cleans the page
6	Text	Inserts text on your whiteboard page
7	Font	Changes the text font of your whiteboard page
8	Image	Inserts an image at your whiteboard page
9	Notes	Creates comments or remarks about your annotation on your whiteboard page
10	Keyboard	Opens a virtual keyboard to insert text on your whiteboard
11	Save	Saves all your activities either as PDF or as JPEG format
12	Show Desktop	Displays your desktop with all running applications. The user can also annotate at the running application using the desktop stylus
13	Arrow	Selects any object or image

Item	Icon	Action
14	Capture Area	The mouse pointer turns into a plus sign. Click the upper left corner of the area you want to capture and drag along the screen to the limit of the capture. The selected area is displayed in gray. The area is then included in the current or new page as an object
15	Previous page	Moves to previous page (when multiple pages added)
16	New page	Creates a new page or to add a new page
17	Next page	Moves to next page (when multiple pages added)
18	Wide Desktop	This icon appears on the whiteboard when two displays are connected to VIA Campus . Using this function, you can send pages from screen 1 to screen 2 and retrieve pages from screen 2 to screen 1. When a participant sends any page to screen 2 and then annotates it on the main VIA Campus screen, those annotations show simultaneously on screen 2. (see Figure 12)
19	Multiple screen	Available when a dual display is connected to VIA Campus . One display can be used for collaboration on the whiteboard and the second can share content from the users. In multiple screens the user can draw on screen 1 and can send this page to screen 2 to show to the audience. (see Figure 13)




Figure 12: Wide Desktop




Figure 13: Multiple Screen

6.10.1 Show Desktop

Show Desktop allows you to hide the whiteboard and to navigate freely on your desktop. A toolbar is available for making annotations on your desktop and capturing an object. For example, capture an area of the screen and add it as an object in your current page.

Icon	Name	Action
	Whiteboard	Press this button to immediately return to your board page
	Pencil	Writes on the whiteboard
	Eraser	Erases precisely what you have written on the whiteboard
	Selection Tool	Selects any object to move it and apply changes
	Capture Area Tool	The mouse pointer turns into plus sign. Click and drag over the desired area
	Window selection	Directly captures a window and all of its content.
	Notes	Adds remarks or comments about the added annotation at the whiteboard
	Virtual Keyboard	Inserts text on the whiteboard
	Save	Saves your activity in either .jpg or .pdf format
	Exit	Exits the whiteboard

6.11 Calling with Skype

VIA Campus lets you call using Skype to any other Skype user in the world.

To activate Skype:

- Click on Features and click on:



Skype launches and you can login and call/chat with any available contact.

6.12 Using GoToMeeting

GoToMeeting is integrated with **VIA Campus**, providing you with a simple and powerful way to hold unlimited online meetings. A **VIA Campus** admin can start a meeting and share his screen with any available user, anywhere in the world.

To launch GoToMeeting,

- Click on Features and click on:



This takes you to the GoToMeeting website (<http://www.gotomeeting.com/fec/>) where you can download the executable file and start an online meeting

6.13 Using WebEx

WebEx is a conferencing program that lets you and others meet online and share files, information, and expertise. WebEx is integrated with **VIA Campus**.

To activate a WebEx online meeting:

- Click on Features and click on the WebEx icon:



This links to the WebEx Web site (<http://www.webex.com/>) from which you can download the app and start online meetings.

6.14 Using Microsoft Lync

Microsoft Lync provides instant messaging, voice over IP and video conferencing.

To start video conferencing with Microsoft Lync:

- Click on Features and click on:  Microsoft Lync

The Microsoft Lync sign-in page opens. The user can login and start messaging or video conferencing.

6.15 Accessing a Web Page

VIA Campus can directly launch a Web browser. You do not need to exit **VIA Campus** to open a Web site, or launch a Web-based presentation.

To open the Web browser:

- Click on Features and click on the Web Browsing icon.  Web Browsing

The default browser (Internet Explorer) opens through **VIA Campus** and you can navigate to any Web site or online video/presentation file.

Note: In the Web management interface of the settings, you can change the default browser to any one you prefer. For more details, see the Web management settings section.

6.16 Using the Settings Menu

Use the Settings menu to configure your **VIA Campus** unit and manage third party applications.

The Settings menu tabs include:

- LAN Settings – configures network parameters.
- Room Name/Room Code – manages room code and name preferences.
- Configurations – Activate Media mode, manage your Cloud directory, etc.
- System Controls – manages your display and audio settings, run control panel, select preferred language, etc.
- Wallpaper – inserts customized wallpaper.
- Third Party Apps – installs/removes third-party software applications.
- Authentication – activates moderator mode and defines moderator/participant settings.
- Mirroring – Enable and configure your iOS mirroring feature.

To open the settings page use keyboard and mouse connected to **VIA Campus** unit:

1. Click on Features to expand.
2. Click on Settings.



3. It requests the password for the **VIA** Super User.
4. Enter the password "supass". The user name is "su" by default.

The Settings screen opens:



Figure 14: Settings Screen

5. After settings are defined, click on the Reboot tab to apply all.

6.16.1 Using LAN Settings

Use LAN settings to change the IP address, DNS and default gateway of **VIA Campus**. Your **VIA Campus** unit is set to DHCP LAN settings by default.



When changing these settings, make sure they are correct. Incorrect values can cause a loss of communication.

To change the default settings:

1. Click on LAN Settings.
2. Select “Static” into the IP Configuration window.
3. Enter as required the IP address, subnet mask, default gateway, DNS server 1.



Figure 15: LAN Settings Screen

4. When finished, click Apply Settings.
5. Click OK at the confirmation message.
6. Click Reboot to restart the system with the new settings.

6.16.2 Room Name/Code Settings

To activate/deactivate Room Code, Date & Time:

- In Settings, click Room Name/Code.

The following screen appears:




Figure 16: Room/Name Code Screen

- **Show Room Name on Wallpaper:** This feature displays the Room Name (a standard IP address) on the **VIA Campus** home screen. By default, it displays the current IP address, but you can change it to a Domain Name System (DNS) name if local DNS services are supported by the network. To change the Room Name, enter the new address or DNS name, then click on Apply and reboot **VIA Campus**. To login any device to the **VIA Campus** client, you must enter the same Room Name in the location field on your device.
- **Activate Room Code:** The Room Code is a security overlay feature that generates and updates a four digit code. It appears on the lower right of the **VIA Campus** home page. When activated, this code must be entered by any device before logging into VIA Campus.
- **Always show on Wallpaper:** If the room code is activated, it always shows on the wallpaper below the room name, otherwise the room code only shows when logging into any client.
- **Show Date Time on Wallpaper:** Displays the date/time on the top right of the display.

- **Show Room Name / Code on second Display also:** Supported only if there is a second display connected to VIA Campus. This feature allows you to show the Room Name on the wallpaper of the second display connected



The color of the text of the room name, the room code, the date and time to show on the background of the **VIA Campus** wallpaper can also be changed in this Settings menu.

6.16.3 Using Configuration Settings

Configuration settings allow the user to change the cloud data path to save cloud data at any desired location. It is also where the user can activate the Media mode.

To change configurations:

- Click on Configurations.




Figure 17: Configurations Screen

The settings include:

- **Activate Media Mode** – If multiple displays are connected to **VIA Campus**, the first display is reserved as the media screen. Multimedia files play only on the first display and the presentation shows on the second display.
- **Activate System Log** – Activates the logging of all system activity either by the client or the gateway to aid diagnosing a problem with **VIA Campus**.
- **Enable Quick Client Access** – Enables a floating icon on the desktop of the **VIA Campus** gateway to open the **VIA Campus** menu. The user can click on this icon and the menu opens.
- **Collaboration Data Directory Path** – Sets the path where all data is saved that has been shared over the cloud by other users. By default, the path is to the internal storage of the SSD (60Gb). The user can attach USB storage to **VIA Campus**, can change the directory path as needed, or point to a network location.

6.16.4 System Control Settings

System controls access the control panel, audio settings, display settings, task manager, system health and log files of VIA Campus. The log folder is only available if system logging is activated from the configurations tab of settings. You can also select the language for the VIA application here.




Figure 18: System Control Screen

VIA Campus is pre-activated by Kramer. If your unit needs to be re-activated, contact Kramer Technical Support.

6.16.5 Wallpaper Settings

This feature allows any corporation or institution to change the default screen to match their branding and in-room equipment usage instructions.

To change the wallpaper:

1. Click Wallpaper.
2. Click Upload Wallpaper.

3. Click Select Wallpaper (must be an image file – jpeg, png, bmp) from your system.
4. Click Reboot.

The background image on **VIA Campus** changes after rebooting.




Figure 19: Wallpaper Screen

6.16.6 Third Party App Settings

The Third Party App feature allows the user to add a shortcut to any third party applications already installed on **VIA Campus**. The user can then launch these applications without exiting **VIA Campus**.

The administrator can also install any other third party application that is not available on the system that a user wants to run.

To add a third party application shortcut:

1. Click on Third Party Apps.
2. Click on Add Application Exe File.

3. Browse to the executable of the application that you want to add as a shortcut, for example go to: C:\Program Files (x86)\Kingsoft\Kingsoft Office\office6 and select wpp.exe to add the shortcut of Word of Kingsoft Office.
4. Click on Reboot.




Figure 20: Third Party Apps Screen

The user can also change the icon image and name of the added third party application.

To change the icon image and name of application:

1. Click on “Advance” tab.
2. The Set Application Name and Icons page opens.
3. Click on “Click here” to browse and change the icon image.
4. Change the application name from “Application Name” field.




Figure 21: Setting Application Name

- If you want to add a shortcut of any of these apps to your main display, check the “add to Shortcut” checkbox for quick access to these apps.



- Close this page and the settings page.

- Reboot the **VIA Campus** hub.

To control the ‘Quick access app’ bar position, open “settings” from the bar and change the bar location.



Welcome to VIA!


Join the meeting

- 1 Connect to the Room Wi-Fi
- 2 Launch the VIA application

First time using VIA?

- 1 Connect to the Room Wi-Fi
- 2 Enter the "Room Name" into your Internet

Look for the VIA app:



Room Name: 10.0.1.4
Code:6721



To Install a Third Party Application:

1. Click on **Install Applications**.
2. When asked to logout as a **VIA Campus** user, click **Yes**.



3. Login again as an administrator and now you can install any application.
The default password is "viaadmin".

Now download any application on your system and install it on the unit. Reboot the system after installation and add the application shortcut under third party apps for future use as explained above.

The user can also create a link with an associated icon to a desired Web page. She/he must give this icon a special "URL Name" and type in his "Web URL", for example:

URL Name	Web URL	Icon	Save_URL
KRAMER LTD	www.kramerelectronics.com		

After rebooting, the link to this specific Web site is accessible from the Third Party Apps icon, in the main feature menu.

6.16.7 Authentication Settings

In this section, you can activate Moderator and Participant modes. In these modes, a participant requires permission from the moderator to use the Step-In function on **VIA Campus**.

To enable Presentation Mode:

1. Click on Authentication.
2. Select Activate Moderator Mode.
3. Select which mode you want to use and reboot **VIA Campus** gateway.




Figure 22: Authentication Screen

There are three different moderator modes:

6.16.8 Database Based

This mode requires building a database of users that can access the system. The users receive credentials (username and password).

There are two default users available to login into **VIA Campus** client in Moderator mode.

Moderator:

- Default user name: su
Default password: supass

Participant:

- Default user name: user
Default password: userpass

Create more users as needed.

To create users:

1. Open the **VIA Campus** Web site by entering the **VIA Campus** IP address in any Web browser (or open a browser from any client PC connected to same network and enter **VIA Campus** IP address).
2. At the top, login with the default moderator username (supass). The moderator can create a database of participants by assigning a Username, Password and Role (Moderator or Participant) to each one of them, as shown in [Figure 23](#) below:



Figure 23: Moderator Mode

Now any user who was created by the moderator can get permission to join the session.

It is also possible to select one or more users to be “Web Administrator”, with the ability to change the settings from the Web administration interface.

To login into the **VIA Campus** client when Presentation Mode is activated:

1. Open the **VIA Campus** client and enter the location (IP address of the **VIA Campus** gateway).
2. Enter user name and password (as defined by moderator).
The Room Code field displays.
3. Enter the room code (if Room Code is activated).
4. Click on **Login**.





Figure 24: Login Screen When Moderator Mode is Active

To start a presentation:

- Click on **“Step-In”** and **VIA Campus** sends a request to the moderator for display permission.



- The moderator clicks on **“Allow”** to start the participant’s presentation on the collaboration display.

The presentation is now visible on the **VIA Campus** main display.

Note: The moderator can "Step-In" at any time without permission.

6.16.9 Active Directory

Groups grant access to resources. Organizational units (OUs) control objects and delegate group policy settings. **VIA Campus** seamlessly integrates with active directories to avoid the inconvenience of creating users from the Web UI of **VIA Campus**.

VIA Campus Gateway contains the following groups that must be mapped with Active Directory groups or organizational units:

- **Moderator:** A user with meeting moderator rights, that is, this user can directly display his screen on a **VIA Campus** Gateway and can allow a participant requesting for presentation on the main display.
- **Participant:** A participant of a presentation session who can join the meeting room but cannot project their desktop without the moderator's permission.

Active directory must have groups or OUs similar to the above Moderator-Participant hierarchy. Do not use groups that have any employee in common.

If there is no such group or OU, create them in such a way that an employee is not in the moderator and the participant group at the same time.

Note: All connecting devices should be governed through this AD or they cannot login.

The screenshot shows the VIA Campus Settings window. The 'Authentication' tab is selected and highlighted with a red box. The 'Active Directory' radio button is selected under 'Authentication Mode'. Below, there are fields for 'Active Directory Domain', 'Moderator', and 'Participant', along with an 'Apply' button.

LAN Settings	Room Name/ Code	Configurations	System Controls
Wallpaper	Third Party Apps	Authentication	Mirroring

Activate Moderator Mode

Authentication Mode

Database Based Active Directory Basic

Active Directory Settings

Active Directory Domain

Group Based OU Based

VIA Group / OU

Moderator

Participant

Apply

ShutDown Reboot

1. Click **Activate Presentation Mode**.
2. Click **Active Directory** under **Authentication Mode**.
3. Under **Active Directory Settings**, type in the Active Directory name in the **Active Directory Domain** text box.
4. Select the **Group Based** or **OU Based** radio button as per your Active Directory configuration.
5. Based on the above selection, type the name of the Moderator and Participant Group/OU in their respective boxes.

Note: **VIA Campus** does not discover and connect to the Active Directory; rather it relies on you to correctly enter the details. If there is a typographical error in any of fields, the users (Moderators and Participants) cannot log in.


6. Click **Apply** and **Reboot** to apply the changes and restart the unit.

For further details, refer to Kramer's white paper "*VIA Integration into DNS and Microsoft Active Directory*".

6.16.10 Basic Moderator Mode

Basic is the simplest moderator mode. By selecting the "Basic" check box and rebooting the system, the VIA unit now selects the first user logged in as the moderator.

At any time, the moderator can leave his role and anyone else can take it.




To login into the **VIA Campus** client when basic moderator mode is activated:

1. Open the **VIA Campus** client and enter the location (IP address of the **VIA Campus** gateway).
2. Enter the nickname.
The Room Code field appears.
3. Enter the room code (if Room Code is activated).
4. Click **Login**.
If you're the first to login, you are the default moderator.
5. Click on "**Leave Moderation**" anytime to stop moderating the session.
Anyone else can now click on "**Become Moderator**" to access this privilege.



6.16.11 Mirroring Settings

By default, the iOS mirroring is enabled and the settings are shown as in the following example:



The VIA AirPlay device is named VIA_AirMirror_XXXX, where XXXX is a random combination of letters and numbers. This is the name that appears when you look for AirPlay devices on your iOS device and it can be changed.

Additionally, it defaults to allow four iOS devices to simultaneously mirror on **VIA Campus**. This setting can also be changed. Once these setting changes have been made, click **Apply**. Reboot **VIA Campus** for the settings to take effect.


6.17 Managing Settings from the VIA Web Management Interface

To manage settings using the Web browser:


Connect your device to the same network that connects to VIA Campus.

1. Open the Web browser and enter the IP address for your **VIA Campus** unit.
The VIA Web interface opens

2. Login as administrator:
Enter user name “su” and password “supass”.
3. Insert the exact presented text on Captcha field to Captcha text field and press the “Login” button



Note: You can change the presented text by pressing the ‘Refresh’ button on the left.




4. Click on VIA Management tab to access the Settings menu.

Note: Any additional user can be created and get “Web administrator” credentials.

6.17.1 Network Settings

Use LAN settings to change the IP address, DNS and default gateway of **VIA Campus**. Apply Settings after finishing.

Information about the Disk Space in use can be found here, as well as the MAC address of **VIA Campus**.



The screenshot shows the VIA Management interface. On the left is a navigation menu with the following items: User Management, VIA Management (highlighted), Network Settings (highlighted), VIA Pad Configuration, VIA Site Management, Wallpaper, Configuration, Authentication, Gateway Features, Client Features(Window/Mac), Mobile Features, Utilities, Audience Response System, Home, and [Logout]. The main content area is titled 'Network Settings' and contains the following elements:

- Network Settings:** A section with radio buttons for 'Static' and 'DHCP' (selected), and an 'Apply' button.
- IP Address:** A text input field containing '10.0.1.0'.
- Mac Address Information:** A table with one row: Mac Address | 30:5A:3A:56:FF:30.
- Diskspace Information:** A table with two rows: Total Disk Size | 55.3 GB and Space Available | 38.1 GB.
- Buttons:** 'Reboot' and 'Shutdown' buttons.

Figure 25: VIA Management - Network Settings

6.17.2 Configuring VIAPad and WiFi


For entities using VIA Pad, the first required step is to configure VIA Campus in order to allow it to pair the VIA Pad devices.

VIAPad Configuration

- **Guest mode:** Enable this mode in case you want the VIA Pad to act as a simple “Step-In / Step-Out” touch device. No client application is shown on the user’s display.
- **VIAPad overrides Room Code:** Enable this feature if you want the VIA Pad to bypass the need to type in the Room Code authentication.
- **Room Name:** Is automatically populated; it reflects the name of VIA Campus.


WiFi Configuration

- **Auto Connect to WiFi:** Enable this feature if you want the VIA Pad to connect automatically to the WiFi network of the Meeting Room. You are prompted for the following details:
 - **SSID:** Enter the name of the WiFi network – Please make sure that you write it EXACTLY as defined, it is case sensitive.
 - **Authentication Mode:** Select the security used by your WiFi router among the preset options (WEP Open/ WEP Shared/ WPA Personal/ WPA2 Personal).
 - **Encryption:** Select the type of encryption key used by your router.
 - **Key:** Type the password required to join your network.



Apply Settings to save the configuration.

Pair your VIA Pad devices as shown below:



6.17.3 Using VIA Site Management

VIA Site Management Server (VSM Server) is an optional software application (subject to a separate pricing) that allows an administrator to monitor and make changes to all connected **VIA Collage/Campus** or **Connect PRO** gateways. It is a Web-based interface that allows the administrator to:

- Add or modify an existing VIA Gateway (**VIA Collage/Campus/VIA Connect PRO**).
- Push various settings like configuration, gateway features, client features, etc. to Campus/Connect units.
- Update VIA Collage/Campus/Connect PRO units from the central server when the updates become available.

- Manage the following statuses for all VIA Collage/Campus/Connect PRO units attached to the VSMS:
 - CPU usage
 - HDD usage
 - Off/on status
 - Configuration and download status
 - Version status

The VSMS can automatically provide individual configuration to added gateways or the settings can be configured locally.

Some changes must be made to the gateway before it can be managed from a VIA Site Management Server.

1. Type the VIA Site Management Server IP.
2. Type a Gateway ID (a gateway ID can be a random number, as long as it is unique. It helps identify the **VIA Campus** or **VIA Connect** unit in question.)
3. Click **Validate and Save** for changes to take effect.
4. Choose the settings “From HQ” to download the setting from the HQ server or choose “From Gateway” to keep the local settings.
5. Click **Reboot** to restart the unit.




Figure 26: VIA Site Management

Note: Contact your regional sales representative for more details about this solution.

6.17.4 Using Wallpaper

This feature allows any corporation or institution to change the default screen to match their branding and in-room equipment usage instructions.

To change the wallpaper:

1. Click on **Upload Wallpaper**.
2. Select Wallpaper (must be an image file – jpeg, png, bmp) from your system.
3. All previously uploaded wallpapers are saved and shown as below. To select one of them, click on **“Set”**.
4. Then click on **Reboot**
The background image on **VIA Campus** changes after rebooting.





Figure 29: VIA Management – Wallpaper


6.17.5 Using Configuration Settings

Configuration settings are:

- **Activate System Log** – Activates the logging of all system activity either by the client or the gateway to aid diagnosing a problem with **VIA Campus**.
- **Activate Media Mode** – If multiple displays are connected to **VIA Campus**, the first display is reserved as the media screen. Multimedia files play only on the first display and the presentation shows on the second display.
- **Disable Always On Top - VIA Minimised icon on Gateway** - Hides the VIA menu icon from the right corner of the main display: 
- **Do Not Disturb** – This feature easily enables a Do Not Disturb mode that allows a user to present to the main display without any interruptions. Clicking the DND button prevents ALL interruptions.
The user that clicked DND has full access to all features:



The other users can see a modified user interface that is only allowing access to two things: View Main Display & Participants' List. The View Main Display icon replaces the Step In button and Features are grayed out:



The user who enabled DND must disable DND to allow other participants to regain full functionality.



- **Facility to Activate/Deactivate Chat by Moderator** – This option is offered to the Moderator of a session, to restrain users from chatting.
- **Activate Third Party Shortcut** – Make a shortcut to your preferred 3rd party apps on the main screen.

Scanning the QR Code


- Check “Enable QR code” and “Bypass room code” (if required) and click the “Reboot” button.

Relocating & Resizing the QR Code

To relocate the QR code on the VIA main display, click and drag it with the mouse and drop it anywhere on the screen



- To resize QR code, click and drag it from the code frame to any desired size.





Display Layout Settings:

- Select the layout between Thumbnail view and dynamic view.
- Activate / Deactivate Auto-Hide Thumbnails (fade out of the side thumbnails after few seconds).

Room Code, Room Name Settings:

- **Show Room Name on Wallpaper:** This feature displays the Room Name (a standard IP address) on the **VIA Campus** home screen. By default, it displays the current IP address, but you can change it to a Domain Name System (DNS) name if local DNS services are supported by the network. To change the Room Name, enter the new address or DNS name, then click on Apply and reboot **VIA Campus**. To login any device to the **VIA Campus** client, you must enter the same Room Name in the location field on your device.
- **Activate Room Code:** The Room Code is a security overlay feature that generates and updates a four digit code. It appears on the lower right of the **VIA Campus** home page. When activated, this code must be entered by any device before logging into **VIA Campus**.
- **Always show on Wallpaper:** If the room code is activated, it always shows on the wallpaper below the room name, otherwise the room code only shows when logging into any client. Set here also the refresh time of the Room Code (30 minutes as default).
- **Show Date Time on Wallpaper:** Displays the date/time on the top right of the display.

- **Show Room Name / Code on second Display also:** Supported only if there is a second display connected to VIA Campus. This feature allows you to show the Room Name on the wallpaper of the second display connected.

The color of the text of the room name, the room code, the date and time to show on the background of the **VIA Campus** wallpaper can also be changed in this Settings menu. Click on the square to select your preferred color.

iOS Mirror:

Activate or deactivate the iOS Mirroring feature:

- When activated the first time, the VIA's AirPlay device is named VIA_AirMirror_XXXX, where XXXX is a random combination of letters and numbers. This is the name that appears when you look for AirPlay devices on your iOS device and it can be changed.
- Additionally, it defaults to allow 4 iOS devices to be mirrored to **VIA Campus** simultaneously. This setting can also be changed. Once these setting changes have been made, click Apply. Reboot **VIA Campus** to allow the settings to take effect.

Auto Power Off Timing:

- Activate this feature to allow the unit to Auto Power Off at a selected time (note that it is a 24 hours based clock).

Language:

- Select your preferred language for your VIA interface.

Date and Time Format for Web Interface:

- Select your preferred Date and Time format.

VIA
KRAMER

Welcome !! 801

User Management

VIA Management

Network Settings

VIA Pad Configuration

VIA Site Management

Wallpaper

Configuration

Authentication

Gateway Features

Client Features(Window/Mac)

Mobile Features

Utilities

Audience Response System

Home

[Logout]

Configuration

Configuration

- Do not start HDMI input on startup
- Activate PIP Mode
- Activate System Log
- Activate Media Mode Enable Quick Client Access
- Disable Always On Top - VIA Minimised icon on Gateway
- Do Not Disturb
- Facility to activate / deactivate chat by Moderator
- Activate Third Party Shortcut

Display Layout

- Deactivate auto-hide thumbnails.

Display Layout

Room Code, Room Name Settings

- Show Room Name on wallpaper
- Activate Room Code
- Always show on wallpaper
- Room Code Refresh Time(Minutes)
- Show Date Time on wallpaper 24 hours format
- Show Room Name/Code on second Display also(Dual Display Only)

Note: Room Name/Code will be shown only if they are active

IOS Mirror

-
- Mirror Name
- Max no of mirrors

Auto Power Off Timing

Hrs Minutes

Activate

Language

Select Language

Date and Time Format for Web Interface

Date Time Format

Figure 30: VIA Management – Configuration

6.17.6 Authentication




Figure 27: VIA Management – Authentication

6.17.7 Using Gateway Features

Manage the features available on the VIA gateway: (see [Figure 28](#))

- Change the default Whiteboard and Web Browsing applications by your preferred ones. Click on the application you want to change and browse your computer to find the one you want to associate as default.
- Remove the features you do not want to offer to the users. Click on the ⊗ on the icon you want to hide. Note that any removed feature is just hidden and not deleted. The space allocated to this specific icon is left blank so you can reorganize manually the order of the icons by simply dragging them to your preferred scheduling. Make sure you click on “Apply” and Reboot your unit to apply these changes.




Figure 28: VIA Management – Gateway Features

6.17.8 Using Client Features

Manage the features available on the VIA client applications (see [Figure 29](#)):

Remove the features you do not want to offer to the users. Click on the ⊗ on the icon you want to hide. Note that any removed feature is just hidden and not deleted. The space allocated to this specific icon is left blank so you can reorganize manually the order of the icons by simply dragging them to your preferred scheduling. Make sure you click on “Apply” and Reboot your unit to apply these changes.




Figure 29: VIA Management – Client Features (MAC/Windows)

6.17.9 Using Mobile Features

Manage the features available on the VIA client applications (see [Figure 30](#)):




Figure 30: VIA Management – Client Features (Mobile)

6.17.10 Using Gateway/Webadmin Activity Logs

Gateway Activity Log

Start Date: 2016-01-03

End Date: 2016-01-03

User: Select

Search

Total number of log entries found: 29

Export to PDF Export to CSV

User Name	Activity Date Time	Remarks
jim	2016-01-03 03:54:31	LoggedIn
dave	2016-01-03 03:56:05	LoggedIn
mike	2016-01-03 03:56:36	LoggedIn
jim	2016-01-03 04:00:55	Display Start
dave	2016-01-03 04:03:45	Display Stop
jim	2016-01-03 04:03:51	Display Stop
mike	2016-01-03 04:08:15	LoggedOut
jim	2016-01-03 04:08:25	LoggedOut
dave	2016-01-03 04:08:27	LoggedOut
dave	2016-01-03 06:38:02	LoggedIn
dave	2016-01-03 06:38:14	LoggedOut

Figure 33: Utilities – Gateway Activity Log

Webadmin Activity Log

Start Date: 2016-01-03

End Date: 2016-01-03

User Name: Select

Action Taken: Select

Search

Total number of log entries found: 3

Export to PDF Export to CSV

User Id	Action Taken	Activity Date	Remarks	Host Name
su	Login	2016-01-03 06:35:10	Success	10.0.1.8
su	Update	2016-01-03 06:36:42	dave Updated	10.0.1.8
su	Update	2016-01-03 06:36:57	mike Updated	10.0.1.8

Figure 34: Utilities – Webadmin Activity Log

6.17.11 Updating Firmware

To update your **VIA Campus** unit through this interface, **ONLY** use the .zip file (as a compressed file – do not try to uncompress it) available for download from our technical support Web page:

<http://www.kramerelectronics.com/support/downloads.asp>




Figure 35: Utilities - Update Firmware

6.17.12 Using Maintenance

On the left menu, click on **Utilities** and select **Maintenance**.

You can select the default configurations you would like to reset one by one or click “Select All” to reset to complete default factory settings.




Figure 36: Utilities – Maintenance

6.17.13 Using the Audience Response System

This feature offers two new modules for interactive learning in education and corporate training environments: e-Polling conducts surveys during collaborative sessions and e-Exam provides interactive multimedia tests for the students.

Both modules are currently in Beta version. Full functionality is expected by Q4-2016.

6.18 User Experience

VIA Campus enables a high level of collaboration in meetings. Participants can share files, chat, edit a common document, or stream full HD (1080p/60) video content. Following is a summary of **VIA Campus** functions:



Wireless Connection

Connect wirelessly with your own device



Enable Control

Give a participant control over a presenter's MAC® or PC laptop



Mobile Mirroring

Show any content from your iOS or Android device on the main display



Chat

Send an instant message to another participant



Full HD Video Streaming

Share uninterrupted full HD wireless video streaming (up to 1080p60) and photos



Third Party Apps

Join the meeting remotely with third-party apps, such as Microsoft Office®, Skype®, GotoMeeting®, Lync®, and WebEx®



Cloud Based

Drag and drop files to the Cloud to share instantly with other users



View Main Display

View the main display on your own device



File Sharing

Share any size file with any number of participants



Web Browser

Open any browser to display content from a Web site



Whiteboard

Annotate, illustrate and edit shared documents: touch-screen compatible



4K-UHD Output

Present 4K-UHD content to compatible 4K-UHD displays



e-Polling

Conduct surveys of student knowledge and opinion to enhance the learning experience



e-Exam

Offer interactive, multi-media tests with instant feedback for students

Collaboration capabilities have been enhanced with the addition of the popular cloud services:


- Google Drive 
- Dropbox 
- OneDrive 
- iCloud (for iOS users only) 

Link your cloud service (Google Drive, Dropbox, OneDrive or iCloud) account to your VIA application for full access to your online documents.

Select one file from your cloud service and select from the following options:

- Open - Open the file on your screen and “Step-In” to share it on main screen.
- Download - Create a copy of your online file to easily access it from your VIA Multimedia Feature.
- Share - Share the selected file using your preferred mailing service.

Alternatively, select one file saved in your VIA Multimedia feature (photo, document or video) and choose to upload it to your cloud service account, for later usage.



Note: Different devices enable different features depending on the device capabilities. See the following illustrations.




Figure 31: Samsung Galaxy




Figure 32: iPhone/iPad




Figure 33: PC

7 Technical Specifications

INPUTS:	2 USB 3.0, 3 USB 2.0, 1 LAN on a RJ-45 connector, 1 unbalanced stereo audio (line or mic), 1 e-SATA
VIDEO OUTPUTS:	1 HDMI, 1 DVI-I
AUDIO OUTPUTS:	Analog line out, embedded HDMI.
PROCESSOR:	2.9GHz quad core, low power consumption
MAIN MEMORY:	4GB, high speed.
LAN:	Gigabit LAN port, 10/100/1000/auto.
STORAGE:	60GB, solid-state drive.
POWER SUPPLY:	90W power adapter (19V, 4.74A).
INPUT VOLTAGE:	100V~220V AC, 50/60Hz, auto sensing.
OPERATING TEMPERATURE:	0° to +40°C (32° to 104°F)
STORAGE TEMPERATURE:	-40° to +70°C (-40° to 158°F)
HUMIDITY:	10% to 90%, RHL non-condensing
DIMENSIONS:	21.2cm x 19.6cm x 5.6cm (8.4" x 7.7" x 2.2") W, D, H.
NET WEIGHT:	1.28kg (2.8lbs).
INCLUDED ACCESSORIES:	3 power cords (US, EU, UK), DVI (M) to VGA (F) Kramer adapter
OPTIONAL:	2U rack adapter
Specifications are subject to change without notice at http://www.kramerelectronics.com	

8 VIA Campus Upgrade Procedure

This section describes the procedure for upgrading the **VIA Campus** firmware.

8.1 Downloading the Upgrade File

1. Go to http://www.kramerelectronics.com/support/product_downloads.asp to check for the latest available firmware upgrades.
2. Select the type of unit to upgrade.
3. Save the downloaded file to your computer and extract all files (the extracted file contains: VIA Campus release notes document, VIA Campus Upgrade procedure document, VIA Campus update zip file).

8.2 Upgrading your VIA Campus

Refer to the "VIA Campus upgrade procedure" included in the downloaded folder.

8.3 Verifying a Correct Installation

From your **VIA Campus** unit, click the Participants icon and check that the correct software version appears on the right side of the screen.

Check the Kramer Web site for the latest firmware version.

8.4 Updating your Computer Client Applications (Windows and MAC)

To download the new client application:

- Connect to the same Wi-Fi network and browse the IP address of the unit.
- The system automatically detects if the user is connected from a Windows PC or a Mac and directs him to download Virtual Run or to install the application accordingly.
- Once the user has installed the new client App, the version appearing on the top right side of Participants shows the correct version.
- This single client application now runs for **VIA Collage**, **VIA Campus** and **VIA Connect PRO** units.

8.5 Updating the Mobile Applications

It is essential that all users download the new client application from the VIA unit.

It is important to update your mobile units as soon as the mobile apps are available in accordance with the firmware upgrade of the VIA, otherwise your mobile devices will not work with the VIA.

LIMITED WARRANTY

The warranty obligations of Kramer Electronics for this product are limited to the terms set forth below:

What is Covered

This limited warranty covers defects in materials and workmanship in this product.

What is Not Covered

This limited warranty does not cover any damage, deterioration or malfunction resulting from any alteration, modification, improper or unreasonable use or maintenance, misuse, abuse, accident, neglect, exposure to excess moisture, fire, improper packing and shipping (such claims must be presented to the carrier), lightning, power surges, or other acts of nature. This limited warranty does not cover any damage, deterioration or malfunction resulting from the installation or removal of this product from any installation, any unauthorized tampering with this product, any repairs attempted by anyone unauthorized by Kramer Electronics to make such repairs, or any other cause which does not relate directly to a defect in materials and/or workmanship of this product. This limited warranty does not cover cartons, equipment enclosures, cables or accessories used in conjunction with this product.

Without limiting any other exclusion herein, Kramer Electronics does not warrant that the product covered hereby, including, without limitation, the technology and/or integrated circuit(s) included in the product, will not become obsolete or that such items are or will remain compatible with any other product or technology with which the product may be used.

How Long Does this Coverage Last

As of this printing, three years for hardware and one year for software updates. Please check our Web site for the most current and accurate warranty information.

Who is Covered

Only the original purchaser of this product is covered under this limited warranty. This limited warranty is not transferable to subsequent purchasers or owners of this product.

What Kramer Electronics will do

Kramer Electronics will, at its sole option, provide one of the following three remedies to whatever extent it shall deem necessary to satisfy a proper claim under this limited warranty:

1. Elect to repair or facilitate the repair of any defective parts within a reasonable period of time, free of any charge for the necessary parts and labor to complete the repair and restore this product to its proper operating condition. Kramer Electronics will also pay the shipping costs necessary to return this product once the repair is complete.
2. Replace this product with a direct replacement or with a similar product deemed by Kramer Electronics to perform substantially the same function as the original product.
3. Issue a refund of the original purchase price less depreciation to be determined based on the age of the product at the time remedy is sought under this limited warranty.

What Kramer Electronics will not do Under This Limited Warranty

If this product is returned to Kramer Electronics or the authorized dealer from which it was purchased or any other party authorized to repair Kramer Electronics products, this product must be insured during shipment, with the insurance and shipping charges prepaid by you. If this product is returned uninsured, you assume all risks of loss or damage during shipment. Kramer Electronics will not be responsible for any costs related to the removal or re-installation of this product from or into any installation. Kramer Electronics will not be responsible for any costs related to any setting up this product, any adjustment of user controls or any programming required for a specific installation of this product.

How to Obtain a Remedy under this Limited Warranty

To obtain a remedy under this limited warranty, you must contact either the authorized Kramer Electronics reseller from whom you purchased this product or the Kramer Electronics office nearest you. For a list of authorized Kramer Electronics resellers and/or Kramer Electronics authorized service providers, please visit our web site at www.kramerelectronics.com or contact the Kramer Electronics office nearest you.

In order to pursue any remedy under this limited warranty, you must possess an original, dated receipt as proof of purchase from an authorized Kramer Electronics reseller. If this product is returned under this limited warranty, a return authorization number, obtained from Kramer Electronics, will be required. You may also be directed to an authorized reseller or a person authorized by Kramer Electronics to repair the product.

If it is decided that this product should be returned directly to Kramer Electronics, this product should be properly packed, preferably in the original carton, for shipping. Cartons not bearing a return authorization number will be refused.

Limitation on Liability

THE MAXIMUM LIABILITY OF KRAMER ELECTRONICS UNDER THIS LIMITED WARRANTY SHALL NOT EXCEED THE ACTUAL PURCHASE PRICE PAID FOR THE PRODUCT. TO THE MAXIMUM EXTENT PERMITTED BY LAW, KRAMER ELECTRONICS IS NOT RESPONSIBLE FOR DIRECT, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM ANY BREACH OF WARRANTY OR CONDITION, OR UNDER ANY OTHER LEGAL THEORY. Some countries, districts or states do not allow the exclusion or limitation of relief, special, incidental, consequential or indirect damages, or the limitation of liability to specified amounts, so the above limitations or exclusions may not apply to you.

Exclusive Remedy

TO THE MAXIMUM EXTENT PERMITTED BY LAW, THIS LIMITED WARRANTY AND THE REMEDIES SET FORTH ABOVE ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES, REMEDIES AND CONDITIONS, WHETHER ORAL OR WRITTEN, EXPRESS OR IMPLIED. TO THE MAXIMUM EXTENT PERMITTED BY LAW, KRAMER ELECTRONICS SPECIFICALLY DISCLAIMS ANY AND ALL IMPLIED WARRANTIES, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. IF KRAMER ELECTRONICS CANNOT LAWFULLY DISCLAIM OR EXCLUDE IMPLIED WARRANTIES UNDER APPLICABLE LAW, THEN ALL IMPLIED WARRANTIES COVERING THIS PRODUCT, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE, SHALL APPLY TO THIS PRODUCT AS PROVIDED UNDER APPLICABLE LAW.

IF ANY PRODUCT TO WHICH THIS LIMITED WARRANTY APPLIES IS A "CONSUMER PRODUCT" UNDER THE MAGNUSON-MOSS WARRANTY ACT (15 U.S.C.A. §2301, ET SEQ.) OR OTHER APPLICABLE LAW, THE FOREGOING DISCLAIMER OF IMPLIED WARRANTIES SHALL NOT APPLY TO YOU, AND ALL IMPLIED WARRANTIES ON THIS PRODUCT, INCLUDING WARRANTIES OF MERCHANTABILITY AND FITNESS FOR THE PARTICULAR PURPOSE, SHALL APPLY AS PROVIDED UNDER APPLICABLE LAW.

Other Conditions

This limited warranty gives you specific legal rights, and you may have other rights which vary from country to country or state to state.

This limited warranty is void if (i) the label bearing the serial number of this product has been removed or defaced, (ii) the product is not distributed by Kramer Electronics or (iii) this product is not purchased from an authorized Kramer Electronics reseller. If you are unsure whether a reseller is an authorized Kramer Electronics reseller, please visit our Web site at www.kramerelectronics.com or contact a Kramer Electronics office from the list at the end of this document.

Your rights under this limited warranty are not diminished if you do not complete and return the product registration form or complete and submit the online product registration form. Kramer Electronics thanks you for purchasing a Kramer Electronics product. We hope it will give you years of satisfaction.

KRAMER



SAFETY WARNING

Disconnect the unit from the power supply before opening and servicing

For the latest information on our products and a list of Kramer distributors, visit our Web site to find updates to this user manual.

We welcome your questions, comments, and feedback.

www.kramerAV.com
info@kramerel.com